
Unit IV : Introduction to solids and semiconductors

Density of states




Failures of Quantum free electron theory

- This theory did not include mean free path.
- Could not explain conductivity of divalent and trivalent atoms
- Relaxation time is assumed to be same for thermal and electrical conductivity but they are not same.
 Phonons also carry thermal energy.
- Fermi surface considered spherical but it is not spherical
- Could not explain metallic properties of crystals


Material	Valency	ρ (Ω∙m) at 20 °C Resistivity	σ (S/m) at 20 °C Conductivity
Silver	1	1.59×10^{-8}	6.30×10 ⁷
Copper	1,2	1.68×10^{-8}	5.96×10 ⁷
Gold	1,3	2.44×10^{-8}	4.10×10 ⁷
Aluminum	3	2.82×10^{-8}	3.5×10^{7}
Zinc	2	5.90×10^{-8}	1.69×10^{7}


Band theory of solids





Kronig-Penney Model








Drift and diffusion current

- Drift current is the electric current, or movement of charge carriers, which is due to the applied electric field, often stated as the electromotive force over a given distance. When an electric field is applied across a semiconductor material, a current is produced due to the flow of charge carriers.
- Diffusion Current is a current in a semiconductor caused by the diffusion of charge carriers (holes and/or electrons). This is the current which is due to the transport of charges occurring because of non-uniform concentration of charged particles in a semiconductor.

P-N Junction







Future Scope and relevance to industry

Devices based on

- p-n Junctions
- Light-Emitting Diodes/Photodetectors
- Bipolar Junction Transistors
- Field Effect Transistors

Research:

https://www.tandfonline.com/doi/abs/10.1080/0256 4602.2003.11417075